



NOTES:

STOCKPILE MUST BE LOCATED IN FRONT OF PROPERTY CONDUCTING WORK AND A MINIMUM OF 5 FEET AWAY FROM ANY DRIVEWAY.

WHEN STORING SAND, GRAVEL, DIRT, ROCK, OR OTHER CONSTRUCTION MATERIALS IN THE PUBLIC RIGHT-OF-WAY THAT COULD POTENTIALLY ENTER THE STORM DRAIN SYSTEM; THE FOLLOWING PROTECTIVE MEASURES SHALL BE ENFORCED:

- ① THE LICENSED AND INSURED CONTRACTOR SHALL OBTAIN AN OBSTRUCTION PERMIT PRIOR TO PLACEMENT OF ANY MATERIALS, EQUIPMENT, ETC. WITHIN THE PUBLIC RIGHT-OF-WAY;
- ② THE CONTRACTOR SHALL PLACE A 4" PVC PIPE ALONG THE CURB TO MAINTAIN DRAINAGE ACROSS THE PROPERTY FRONTAGE. THE MINIMUM LENGTH OF THE PIPE FROM THE END OF THE SANDBAG SHALL BE 12 INCHES.
- ③ THE CONTRACTOR SHALL PLACE A VISQUEEN / PLASTIC (10 MIL. MIN. THICKNESS) MAT OF SUFFICIENT SIZE TO COMPLETELY CONTAIN THE MATERIAL(S) WITH A MINIMUM OVERLAP OF 3 FEET FROM THE STOCKPILE AND A SANDBAG PERIMETER BERM STACKED 1 HIGH;
- ④ THE CONTRACTOR SHALL WRAP THE VISQUEEN UNDER THE SANDBAG PERIMETER BERM, AND TUCK THE PLASTIC UNDER THE BOTTOM LAYER OF SANDBAGS SO THAT IT IS HELD IN PLACE;
- ⑤ AT THE END OF EACH WORK DAY, AND/OR WHEN A POTENTIAL FOR RAIN EXISTS, THE CONTRACTOR SHALL COVER THE ENTIRE STOCKPILE AND SANDBAG PERIMETER, THAT MAY BE HELD IN PLACE WITH AN ADDITIONAL LAYER OF SANDBAGS STACKED 1 HIGH OR WEIGHTED DOWN WITH AS MANY SANDBAGS AS NECESSARY TO PREVENT THE VISQUEEN PLASTIC FROM FLYING AWAY.
- ⑥ BOTH VISQUEEN TO BE WRAPPED BETWEEN THE 2 SANDBAGS.

APPROVED:

[Signature]

CITY ENGINEER

CITY OF HUNTINGTON BEACH

DEPARTMENT OF PUBLIC WORKS



REVISION DATE: May 2008

MATERIAL STORAGE IN R/W

STANDARD PLAN

111
1 of 1